

# Flair Showers

## Standard Base or Raised Base?

All of the cubicles we make at Flair Showers are Free Standing. This makes the install much easier for you as there is no need to bed the shower cubicle into mortar, saving time. Our bases are reinforced with ply and levelling pads to insure a solid, quality base that will not leak or crack. We offer two variations – the Standard Base and the Raised Base.

## What is the Difference ?

The Standard base is recommended for installs where the cubicle will be placed on a timber floor with under floor access or new builds where the waste can be set up in the slab when poured. The slab will have to be cut when a low step/hob is required.

The Raised Base is an option for people installing their cubicle on a concrete floor. By purchasing a Raised Base, you can simply redirect the waste outlet under the shower without the need for the expensive time consuming task of cutting your concrete floor. Another option would be to redirect the waste outlet to an existing waste pipe, or through an adjoining wall to another waste point/pipe.

